







PIN SYSTEM INSTALLATION / INSTALACIÓN PIN SYSTEM / MONTAGE PIN SYSTEM /  
PIN SYSTEM INSTALLAZIONE / MONTAGE PIN SYSTEM


**PATENT**  
PENDING




Motorcycle

<b>1</b> REF. 262057 M5			<b>2</b> REF. 304114 M5 x 25 DIN 913		x2	REF. 300009 M5 x 10 DIN 913		x1
	x4		REF. 300010 M5 x 16 DIN 913		x1			


**1**



**2**




**3**






2.5 N·m


PLATE INSTALLATION / MONTAJE PLETINA / MONTAGE HALTEPLATTE /  
INSTALLAZIONE SUPPORTO / MONTAGE PLATINE




Tank Bag

<b>3</b> REF. 20120N		<b>4</b> REF. 262055		<b>5</b> REF. 304208 Torx 20 Ø 4 x 16		x3
----------------------	---	----------------------	---	---	---	----


**4**




**5**




- (GB)** Check your bag's manual before the installation of the fitting plate.  
Always use the security strap.
- (E)** Consulte el manual de su bolsa antes de instalar la pletina.  
Utilice siempre la correa de seguridad.
- (D)** Vor Montage der Halteplatte, bitte die Anleitung des Tank Rucksackes beachten.  
Sicherheitsriemen immer befestigen.
- (I)** Consultare il manuale d'istruzioni del suo zaino prima dell'installazione del supporto.  
Utilizza sempre la cinghia di sicurezza.
- (F)** Consultez la fiche d'instuctions de votre sacoché avant l'installation de la platine.  
Toujours utiliser la sangle de sécurité.



E16P



E10P



E04P